

EGRESS WINDOW WELL

INSTALLATION INSTRUCTIONS

INCLUDES

- (6) Dual-Lock Discs
- (6) Dual-Lock Self-Adhesive Pads
- (6) 3/4" Screws

INSTALLATION

1. You will be installing (6) Dual-Lock Disc and Pads to your well and cover.
 - a. (2) will be installed 8" from the foundation wall, centered on the rim of the well.
 - b. (2) will be installed 30" from the foundation wall, centered on the rim of the well.
 - c. (2) will be installed 10" from the center point of the well.
2. Using a marker or pencil and a tape measure, measure and mark all (6) hardware locations. NOTE: Be sure to make markings as close to the center of the rim as possible.
3. Attach (6) Dual-Lock Discs at marked locations using the screws provided.
4. Once the Dual-Lock Discs are attached, place your window well over the well, ensuring it is centered. Use your pencil or marker to mark the center of the Dual-Lock Discs.
5. Using these marks, remove backing from each Dual-Lock Self-Adhesive Pad and adhere them to the underside of the cover. NOTE: Each pad should be placed so it can attach to the corresponding disc.
6. Let the adhesive cure for at least 1 hour. Once cured, align each Dual-Lock Self-Adhesive Pad with the corresponding Dual-Lock Disc and firmly press down until you feel the structures interlock.

