

# SLATEWELL EGRESS WINDOW WELL

## INSTALLATION INSTRUCTIONS

### PREPARATION

Review local building codes to ensure compliance.

Contact Diggers Hotline prior to excavating.

Ensure faucets, downspouts, sprinklers, and hoses are at least 10' from the well and are aimed away from the well.

Excavate a hole that is 18-24" wider than the well in all directions and 10" below the bottom edge of the window.

### INSTALLATION

1. Mark the location of the mounting holes on the foundation. The location of the mounting holes should be 57 1/2" from center to center. *NOTE: The holes must be drilled to these measurements to ensure window well cover fits properly.*
2. Drill two holes on the markings and remove all concrete dust from the holes before proceeding.
3. Install top two anchors in the hole and place well on the anchors.
4. Use a level to ensure well is oriented properly. Remove well from anchors and drill remaining mounting holes at marked locations.
5. Place remaining hardware into the holes, add 1" flat washers and nuts and tighten into place using hand tools.
6. Using hand tools only, backfill around the well in 6-8" layers. Each layer should be packed down to ensure proper support of the steps.

Mounting  
Hole

